

### NOTES:


1. THIS DETAIL SHOWS THE TYPICAL FINAL WATER METER CONFIGURATION AFTER INSTALLATION OF A PROPOSED WATER METER, RECONNECTION OF AN EXISTING WATER METER, OR RELOCATION OF A WATER METER.

SHEET 1 OF 1


#### NOTES:

- 1. THIS DETAIL SHOWS THE TYPICAL FINAL FIRE HYDRANT CONFIGURATION AFTER INSTALLATION OF A PROPOSED FIRE HYDRANT, RECONNECTION OF AN EXISTING FIRE HYDRANT, OR RELOCATION OF A FIRE HYDRANT.
- 2. KEEP DRAIN PORTS FREE FROM OBSTRUCTION.
- 3. RESTRAIN ALL PIPE JOINTS AND FITTINGS. ACCEPTABLE TYPES OF RESTRAINT INCLUDE RESTRAINING GLANDS; RESTRAINED, PUSH-ON JOINTS; AND 3/4" BITUMINOUS COATED, ALL-THREAD RESTRAINING RODS. THRUST BLOCKS ARE NOT AN ACCEPTABLE TYPE OF RESTRAINT.
- 4. FOR RELOCATED OR RECONNECTED FIRE HYDRANTS, VERIFY THE VALVE IS RESTRAINED TO THE MAIN. PROVIDE APPROPRIATE RESTRAINT.

- 5. HYDRANT LOCATION APPLIES TO PROPOSED AND RELOCATED FIRE HYDRANTS.
- 6. LOCATE FIRE HYDRANT WITH 3' HORIZONTAL CLEARANCE FROM ABOVE GROUND OBJECTS.
- 7. PROVIDE A MINIMUM OF 3' COVER OVER ALL SECTIONS OF HORIZONTAL PIPE. USE FITTINGS AS NECESSARY.
- 8. TAPPING SLEEVES MAY BE USED ON EXISTING MAINS IN LIEU OF DI TEES.
- 9. LOCATE FIRE HYDRANT OUTSIDE OF THE VEHICLE RECOVERY AREA, ADJACENT TO THE R/W LINE, OR IN A PROTECTED AREA.



SHEET 1 OF 1



SHEET 1 OF 1

SHEET 1 OF 1 1525.02

32" 3 #6 DOWELS FLOWABLE FILL 4"x8"x16" CMU **BLOCK WALL PLAN** 

#### NOTES:

- 1. THIS DETAIL SHOWS THE CONFIGURATION OF AN OUTSIDE DROP WITH A PRECAST CONCRETE MANHOLE.
- 2. INSERT THREE #6 DOWELS INTO THE BASE OF THE PRECAST MANHOLE BEFORE POURING CAST IN PLACE TONGUE. FACTORY DRILL OR CAST THE DOWEL HOLES IN THE BASE. EPOXY THE DOWELS INTO PLACE. EMBED DOWELS A MINIMUM OF 6" INTO THE MANHOLE BASE AND THE TONGUE. CENTER DOWELS VERTICALLY AND HORIZONTALLY. PLACE DOWELS 12" ON CENTER.
- 3. BLOCK WALL TO SPRING LINE OF HORIZONTAL PIPE.
- 4. USE FOR DROP INLET PIPES UP TO 12".
- 5. USE PC 350 DUCTILE IRON PIPE and FITTINGS FOR THE DROP ASSEMBLY. THE DROP ASSEMBLY SHALL BE THE SAME PIPE DIAMETER AS THE INLET PIPE.

# PLACE TEE FLUSH TO MANHOLE WALL #4 REBAR, 16" O.C. 4"x8"x16" CMU **BLOCK WALL** PLACE BEND FLUSH TO MANHOLE WALL PRECAST MANHOLE BASE 3 #6 DOWELS

# SECTION X-X

CAST IN PLACE TONGUE

# FOR DRAWING STANDARD **ROADWA**

## **GENERAL NOTES:**

HORSESHOE OR CORED OPENING

NEW

CORED

**OPENING** 

EXISTING PIPE

INLET

- 1. THIS STANDARD DETAIL DESCRIBES THE USE OF HORSESHOE TYPE and CORED MANHOLES WITH A CAST-IN-PLACE BOTTOM.
- 2. USE HORSESHOE TYPE MANHOLE ONLY WITH THE PERMISSION OF THE ENGINEER.
- 3. FOR HORSESHOE TYPE MANHOLES, WRAP THE PIPE WITH BUTYL RUBBER GASKET, AND SEAL WITH NONSHRINKING GROUT.

11

11

11 11


11

SECTION X-X


1.1

1.1

11



# SECTION Y-Y CORED PIPE TYPE





(SEE SHEET 2 FOR FOOTING REINFORCEMENT)

SECTION Y-Y HORSESHOE TYPE


SHEET 1 OF 2

ROADWAY





REINFORCED CONCRETE FOOTING FOR 4' PRECAST MANHOLE PRECAST MANHOLE OR **PRECAST MANHOLE** 



MAX. OF 4" FROM THE TOP OF THE SLAB.